

## New functions and addendum

This document contains descriptions of how to set the new functions and their restrictions of WV-V1170. It is recommended to read them while referring to the Operating Instructions provided with this product together.

Due to software upgrade, the following functions have been added and changed to this product.

### ·Firmware Ver.2.61

No.	Functions	Item (Page)	Page
1	Display or not display "PTZ" button on the "Live" page	PTZ function (Live)	1
2	Addition of RS485 operation (PTZ) setting	PTZ Setting (System)	2
3	Addition of Panasonic alarm protocol notification	Notification (Event)	3

### 1. Display or not display "PTZ" button on the "Live" page

PTZ button is available only when the [RS485 operation] in the [PTZ Settings] menu is set to "ON(PTZ)". See ch.3 of Operating Instructions.

If you click this PTZ button, the screen to control the pan/tilt head will be displayed.



## 2. PTZ Setting

Add RS485 operation setting on PTZ setting menu.

See ch.7.6.2 of Operating Instructions.

PTZ Settings

Protocol: PELCCOD

Address: 1

Baudrate: 9600

Data Bit: 8

Stop Bit: 1

Parity: None


RS485 operation:  ON(PTZ)  OFF

Default Refresh Save

<b>RS485 operation</b>	<p>Determine whether or not to display items related to RS485 transmission on the “Live” page.</p> <ul style="list-style-type: none"><li>- ON(PTZ): Displays a screen and PTZ button that uses RS485 transmission to control the pan/tilt head.</li><li>- OFF: Does not display items related to RS485 transmission.</li></ul> <p>Default: OFF</p>
------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 3. Notification

Add the settings relating to Panasonic alarm protocol notification can be configured in this section. See ch.7.4.5 of Operating Instructions.



#### Panasonic alarm protocol notification

##### [Panasonic alarm protocol]

Select "ON" or "OFF" to determine whether or not to provide notification by Panasonic alarm protocol according to the settings for the "Alarm" checkboxes of "Destination of notification" below.

- When an alarm is detected ("Alarm")
- Default: OFF

##### Note

When "ON" is selected, notification of the alarm occurrence will be provided to the registered destination server addresses in order (to IP address 1 first, to IP address 8 last).

##### [Destination port]

Select a destination port for the Panasonic alarm protocol from the following.

- Available range: 1 - 65535
- Default: 1818

##### [Retry times]

Select a retry time for the Panasonic alarm protocol.

- Available range: 0-30
- Default: 2

**Destination of notification**

[Address 1] - [Address 8]

Enter the destination IP address of the Panasonic alarm protocol from the following. Up to 8 destination server addresses can be registered.

- [Alarm] checkbox: When the checkbox is checked, the Panasonic alarm notification will be provided upon an alarm occurrence.

[Destination server address]: Enter the destination server address.