

To prevent unintended camera access by unknown third party

“User name/Password” setup now required upon first time access

Before accessing a network camera (hereinafter referred to as “camera”) via the Internet, be sure to register a user name and password to prevent the invasion of the privacy/portrait right and the occurrence of information leakage owing to unintended access by an unknown third party.

The following function additions and improvements were made to enhance the security in April, 2016*1.

- Added the “Administrator registration” window for the first time access
 - Made the default values of user name/password unavailable and changed the input characters limitations
(The conventional default password “12345” is unavailable for registration.)
- *1 Software Ver.2.40 or later

How to register an administrator for the first time access

1. The “Administrator registration” window will be displayed when accessing a camera for the first time.
(* The default of the camera’s user authentication setting is On.)



2. Enter “User name”, “Password” and “Retype password” by following the instructions displayed on the screen, and then click the [Set] button.
IMPORTANT
 - It is recommended to change the password periodically.

3. After completing the registration, the camera will automatically be re-connected and the authentication window will be displayed. Enter the registered user name and password to start operation.

Request to manage the user name and password

If you forgot the user name or password, the initialization of the camera*2 is required. Since all the edited settings are to be erased and reset when the initialization of the camera is performed, write down the registered user name and password in order not to forget in the note section provided below and store it carefully to keep it out of sight of an unknown third party.

*2 Refer to the Important Information or the Installation Guide provided with this product for how to perform initialization.

User name		Password	
-----------	--	----------	--

ネットワークカメラの第三者アクセス防止のため

初回アクセス時のユーザー名／パスワード登録のお願い


インターネット経由でネットワークカメラ（以下、カメラ）にアクセスする際は、第三者からの意図しないアクセスによるプライバシーや肖像権の侵害、情報漏えいなどを未然に防止するために、ユーザー名／パスワードを必ず登録してください。

2016年4月※¹からセキュリティ強化のため以下の機能を追加・変更しました。

- 初回アクセス時の管理者登録画面を追加
 - ユーザー名／パスワードの初期値の廃止と入力文字制限の変更
(従来のパスワードの初期値 “12345” は登録できません)
- ※ 1 製品品番が「DG-」、「WV-」で始まる機種とWJ-GXE100、WJ-GXE500：ソフトウェア Ver.2.40以降
製品品番が「BB-S」で始まる機種：ソフトウェア Ver.4.60以降

初回アクセス時の管理者登録方法

1. カメラへの初回アクセス時に管理者登録画面が表示されます。
(※カメラのユーザー認証設定は、初期設定：On です)



2. 画面に従って管理者のユーザー名、パスワード、およびパスワード確認を入力し、[登録] ボタンをクリックしてください。
重要
 - パスワードは定期的に変更してください。

3. 登録完了後、カメラに自動で再接続し、認証画面が表示されますので、登録したユーザー名、パスワードを入力してご使用ください。

ユーザー名、パスワードの保管についてのお願い

ユーザー名、パスワードが分からない場合、カメラの初期化※²が必要です。カメラを初期化すると設定がすべて消去されますので、忘れないように下記メモ欄に記載し、第三者の目に触れないように大切に保管してください。

※ 2 初期化の方法については、本製品に付属の取扱説明書 基本編、または設置編を参照してください。

ユーザー名		パスワード	
-------	--	-------	--

