正誤表

取扱説明書　設置編に記載の誤りがありました。以下に内容を記載します。

重要

Step 4　③でカメラ画角調整終了後、以下の作業を追加してください。

●チルト固定ねじの 1 か所（プラスねじ側）を締めてください。
（推奨締付トルク：0.59 N・m {6 kgf・cm}）

メモ

Step 4　③でカメラの画角調整時、以下に注意してください。(SFV631L) (SFV611L)

●天井取り付け時の画角調整において、カメラの向きによってはエンクロージャーと設置補助ワイヤーが画面に映ることがあります。画面に映らないようにエンクロージャーや設置補助ワイヤーを移動してください。



WV-SFV631L/ WV-SFV611L

取扱説明書　基本編、設置編に記載の誤りがありました。以下に内容を記載します。

■別売品について

誤	
カメラ天井埋込金具：	(SFV631L) (SFV611L) WV-Q169A (SFN631L) (SFN611L) WV-Q174B
正	
カメラ天井埋込金具：	(SFN631L) (SFN611L) WV-Q174B



WV-SFN631L / WV-SFN611L

avs1213-2014　PGQW1560XA　Printed in China

CORRIGENDA

Installation Guide contain misdescription. Refer to the following contents and confirm the descriptions that are corrected.

IMPORTANT:

After adjusting the angle of view in ③ of Step 4, perform the action below.

- Tighten the cross slot tilting lock screw.
  (Recommended tightening torque: 0.59 N・m {0.44 lbf・ft})

Note:

When adjusting the angle of view in ③ of Step 4, take care of the following.
SFV631L SFV611L SFR631L SFR611L

- When adjusting the viewing angle for cameras mounted to ceilings, the enclosure and installation auxiliary wire may be displayed on the screen depending on the direction the camera is facing. Move the enclosure and installation auxiliary wire so that they are not displayed on the screen.



WV-SFV631L / WV-SFV611L



WV-SFN631L / WV-SFN611L / WV-SFR631L / WV-SFR611L
SFR631L SFR611L

Important Information contain misdescription. Refer to the following table and confirm the descriptions that are corrected.

■ Optional accessories

Wrong	Right
・English Extended Sun Shade ・French Visière pare-soleil prolongée	・English Sun Shade ・French Visière pare-soleil