

New functions and addendum

- This document contains descriptions of how to set the new functions and their restrictions. It is recommended to read them while referring to the Operating Instructions provided with this product together.
- Depending on the model used, the screens shown in the explanations may differ to the actual camera screens.
- The model number is abbreviated in some descriptions in this manual.
- This document is for the following models.
WV-X6533LN, WV-S6532LN

Due to software upgrade, the following functions have been added and changed to this product.

- **Firmware Ver.4.20**

No.	Functions	Item (Page)	Page
1	Addition of "Manual Pan/Tilt speed" setting to the "Cam. Function"	Cam. Function (Image/Audio)	2

1. Addition of “Manual Pan/Tilt speed” setting to the “Cam. Function”

(Operating Instructions Configure the settings relating to images and audio [Image/Audio]

- Configure the settings relating to the camera operations [Cam. Function])

Add the "Manual Pan/Tilt Speed" selection function to the camera operating setting.

Image	Cam. Function	Image/Position	Audio
Home position	<input type="text" value="Off"/>		
Self return	<input type="text" value="Off"/>		
Self return time	<input type="text" value="1min"/>		
Upside-down	<input type="radio"/> On <input checked="" type="radio"/> Off		
HD Extra optical zoom	<input type="radio"/> On <input checked="" type="radio"/> Off		
Digital zoom	<input checked="" type="radio"/> On <input type="radio"/> Off		
Number of Privacy zone	<input type="radio"/> 8 <input checked="" type="radio"/> 32		
Privacy zone	<input type="text" value="Filling"/>		
Camera position display	<input type="text" value="Pan-Tilt degree/Zoom ratio display"/>		
Operation mode display	<input checked="" type="radio"/> On <input type="radio"/> Off		
Tilt Angle	<input type="text" value="-30°"/>		
Focus distance	<input type="radio"/> Unlimited <input checked="" type="radio"/> Limited		
Manual Pan/Tilt speed	<input type="text" value="Normal"/>		

[Manual Pan/Tilt speed]

Set the operating speed when pan/tilt is operated with the controller.

Set to "TYPE1" or "TYPE2" when using VMS (Video Management System).

Normal : Use this setting when not using VMS.

Type1 : Change the pan/tilt speed change from the tilt of the controller to match the operations in VMS.

Normally use this setting when using VMS.

Type2 : Change to a different setting from "Type1" with the pan/tilt speed change the tilt of the controller.

If the operability is poor when set to "Type1", try this setting. The operability may get improved.

Default : Normal